DC-DC Step-Down Converter



Summary & Applications

This product is designed to provide a reduced supply to power auxiliary electrical systems, is configured specifically for electric vehicles. The NQZB Series DC/DC Converters achieve unmatched power levels of high efficiency and safety.

The devices provide provide a regulated output of 12.5 or 24.5 volts for vehicles lamps and solar applications etc, also provides 13.5 or 27.0 volts for charging auxiliary batteries.

Features


- ◆ Replace diode rectification with synchronous, over90% efficient as high power density
- ◆ Available for maximum pulse power exceeds 120% of the nominal rating
- ◆ Wide voltage input, suitable for battery applications (cell voltage of 1.65V ~ 2.50V)
- ◆ Smaller, lighter and significantly more quiet than conventional converters
- ◆ Short circuit / overload output protection (resume after the short circuit disappear)
- ◆ Applicable to a variety of environmental, protection class IP54

© Copyright DCI All Rights Reserved



Naming rules

The naming rules of DC-DC converter in Figure 1.



Specification


◆ Non 48V input range converters major technical indicators

Model	Input Voltage	Input Voltage Range	Output Voltage	Output Current	Size
NQZB800-048-012C	48V	36V~60V	12V	0~80A	152*76*220mm
NQZB800-060-012C	60V	48V~72V	12V	0~80A	152*76*220mm



Mode of connection


Non isolated power ports defining and wiring as shown below




© Copyright DCI All Rights Reserved



Installation size (Unit: mm)





Note: L=160mm

Figure 4 Installation Size

Precautions

Installation & safety instructions

- ◆ The converter must be mounted on solid metal, aluminum for heat dissipation. The converter will be very hot during use, keep wiring from touching the converter and or do not touch it!
- ◆ Confirm battery pack main positive and negetive potentials!
- ◆ For older cars using a negative through key switch you must use a relay for converter activation. Consult technical services for this application. For radio memory you must either leave the key switch in the on position or hardwire the yellow and red wire to 36/48/60/72 volt positive. Doing this you will have a constant drain on the battery pack and long extended period of "setting" will help drain the battery pack. It is advised for long storage to disconnect the converter.
- ◆ Anytime a battery pack is disconnected manufacturers instructions must be followed.

 Always make sure if the car has a run/tow switch the switch is placed in the tow position

 © Copyright DCI All Rights Reserved



before disconnecting anything. Torque battery cable nuts to 80 to 100 inch pounds. Spray coat connections with anti corrosion spray. Tech Note: loose connection create heat and arcing make sure all wiring connections are clean and tight.

- ◆ Make sure all wiring is free from moving parts, sharp objects or extreme hot area's! Tie up any loose wiring
- use process equipment will pay attention to timely remove surface dust and other debris impact of heat dissipations.
- ◆ Please don't disassemble the DC-DC converter yourself . it may cause electric shock or other injuries .
- ◆ In order to avoid damaging the power cord, don't put any object on the line and place the line where it will not be stepped on . If the cord is frayed or damaged, replace it immediately

Warranty: 12 months Limited Warranty from time of delivery